

Poly Post Kit (100900)

This extremely versatile post is made to use coupler pockets to provide custom fitting of handrails, grab posts, or as an accessory attachment post. Eight embedded T-nut locations for attaching cleats and other EZ Dock products. Recessed holes that can be drilled through for tube and rope handrails.



Installation

Tools Required:

Ratchet
15/16" Socket

1. Place hardware connector in the bottom pocket on the dock in the chosen location.
2. Slide the post into position using the molded connector and coupler pocket on the dock.
3. Bolt the handrail post to the bottom coupler pocket using the 5/8" bolt and washer.

ITEM	QTY.	PART NO.	DESCRIPTION
1	1	S10900	HANDRAIL POST
2	1	S21141SS	HARDWARE CONNECTOR
3	1	80584SS	5/8" X 3.5" BOLT
4	1	117013	WASHER

Handrail options for Poly Post Kit (100900)

Installation

Tools Required:

1-1/2", 1" Drill bit
Drill
Saw



Option A (H10900)

1. Using at least 2 Poly Post Kits (100900), drill 1-1/2" holes in the recessed holes.
2. Cut the 1.5" tube to length and slide through the drilled, recessed holes.
3. Attach the universal plug on both ends of the handrail.

ITEM	QTY.	PART NO.	DESCRIPTION
1	1	R14013	HANDRAIL TUBE 1.5", 113"
2	2	S90000	1-1/2" PLUG
3	2	80556SS	PHILLIPS TECH SCREW

Option B (9000035 or 9000036)

1. Using at least 2 Poly Post Kits (100900), drill 1" holes into the recessed holes.
2. Insert the rope into the recessed holes and secure

ITEM	QTY.	PART NO.	DESCRIPTION
1	N/A	9000035/3000036	ROPE, SOLD BY THE FOOT



9000035



9000036

